Top

4

The Bitsy Bag

Back Exterior Pocket Cut 1x Exterior fabric Cut 1x lining fabric

www.yoansewingstudio.com

©Copyright 2024 YoanSewingStudio

1 inch

2 cm

Print at "actual size" or "100%. Do not scale.

Print orientation: Auto

test squares (test your printer)

Seam allowances are included in this pattern

To ensure accuracy open the pattern with Adobe Reader.
Free download at www.adobe.com/reader

Top

1

The Bitsy Bag

Front Exterior - Upper Panel
Cut 1x Exterior fabric

Back Interior - Upper Panel
Cut 1x lining fabric

www.yoansewingstudio.com

©Copyright 2024 YoanSewingStudio

2

Top

The Bitsy Bag

Front Exterior - Lower Panel
Cut 1x Exterior fabric

Back Interior - Lower Panel Cut 1x lining fabric

www.yoansewingstudio.com

Top

2

The Bitsy Bag

Main Body Panel Cut 1x Exterior fabric Cut 1x Lining fabric

www.yoansewingstudio.com

PATTERN SYMBOLS



NOTCHES indicate matching points of the pattern pieces.

П

Center Fold Line - snip or mark about 1/8" (6mm) on this line.

Top

5

The Bitsy Bag

Front Interior Mesh Pocket Cut 1x Mesh fabric

www.yoansewingstudio.com

6

The Bitsy Bag

Back Exterior Stabilizer
Cut 1x stabilizer

www.yoansewingstudio.com

The Bitsy Bag Project - Supplies and tools

у	loanSewingStudio	2
U	- your	

Fabric	58" (148 cm) wide	44" (112 cm) wide
Exterior	1/4 yard (23cm)	1/4 yard (23cm)
Lining	1/3 yard (30.5cm)	3/8 yard (34.3cm)
Mesh Fabric	6 1/2" x 6 1/2" (16	.5cm x 16.5cm)

⁻The yardage requirements are estimated. More fabric may be needed if using directional print. -Suggested fabric choice (exterior): canvas (all types), denim, linen, home decor fabric -Suggested fabric choice (lining): cotton quilting/lightweight cotton, PUL fabric, nylon ripstop.

Stabilizer and interfacing

•7 1/2" x 14" (19 x 35.5cm) midweight stabilizer such as decovil light, Pellon 808 or 809.

Zipper

- •Double pull nylon coil zipper at least 13" (33cm) long, 1 1/4" (32mm) wide; size #5 or #4.5; for the zipper closure.
- •2x Nylon coil zipper at least 7" (18cm) long, 1 1/4" (32mm) wide; size #5 or #4.5 (for the front exterior pocket & back interior pocket)

Hardwares

- •2x 3/4" (19mm) inner measurement d-rings
- •1x 1" (25mm) inner measurement adjustable strap slider
- •2x 1" (25mm) inner measurement swivel hooks.

Other

- •Webbing Strap 1" (25mm) wide, 55" (140cm) long
- •1/8" or 1/4" basting tape
- •Single fold bias tape 3/4" (19mm) wide about 2 yard (1.9m).
- •Fold over elastic 3/4" (19mm) wide; 5 3/4" (14.5) cm long
- Polyester thread

Tools

- •Sewing machine, basic sewing notions, zipper foot,
- •Clear ruler, rotary cutter or fabric scissors, disappearing fabric marker
- •Pattern weights, sewing machine needle size 90/14 & 100/16, hand sewing needle.

Finished bag measurements 5 1/2" wide x 8" tall x 2" deep (14 x 20.3 x 5 cm)

Designed by : Yoan Zivkovic Skill Level: Intermediate

Features

Front Exterior Zipper Pocket Back exterior slip pocket Zipper closure Adjustable Strap Interior zipper pocket Interior mesh pocket

Watch the full video tutorial https://youtu.be/O1hreXG4dBQ

Seam allowances are 1/4" (6mm) unless otherwise stated, land are included in the pattern.

To ensure accuracy open the pattern with Adobe Reader.
Free download at www.adobe.com/reader

NOTES

- •After cutting each panel from the pattern pieces, immediately transfer and cut all the notches and marking lines.
- Fuse the decovil stabilizer to the wrong side of the back exterior panel and lower gusset panel (centered).
- Pay close attention to the pattern pieces labeled with "Top". Mark the "Top" of the fabric after cutting.
- If your fabric has directional print, do assessment before cutting to achieve the desired look.
- Watch the full instructions in the video tutorial https://youtu.be/O1hreXG4dBQ
- Share the pictures of your finished bag on instagram #yoansewingstudio

The Bitsy Bag Project I



~Cutting Instructions~

Following the below chart, cut your fabric, stabilizer, and interfacing accordingly.

Name	Exterior Fabric	Lining Fabric	Stabilizer
Front Exterior - Upper	Cut (1) - Pattern 1		
Front Exterior - Lower	Cut (1) - Pattern 2		
Front Exterior Zipper pocket Lining		Cut (1) 6 1/4" w x 11" h (16 x 28 cm)	
Back Exterior - Main Body	Cut (1) - Pattern 3		Cut (1) - Pattern 6
Back Exterior Pocket	Cut (1) - Pattern 4	Cut (1) - Pattern 4	
Ring Tabs	Cut (2) 2" x 1 1/2" (5 x 3.8 cm)		
Front Interior - Main Body		Cut (1) - Pattern 3	
Back Interior - Upper		Cut (1) - Pattern 1	
Back Interior - Lower		Cut (1) - Pattern 2	
Back Interior Zipper pocket Lining		Cut (1) 6 1/4" w x 11" h (16 x 28 cm)	
Zipper Gusset	Cut (1) 2 3/4" w x 12" (7 x 30.5 cm)	Cut (1) 2 3/4" w x 12" (7 x 30.5 cm)	
Lower Gusset	Cut (1) 3" w x 14 1/2" (7.5 x 37 cm)	Cut (1) 3" w x 14 1/2" (7.5 x 37 cm)	Cut (1) 2" w x 13 1/2" (5 x 34 cm)

Front interior mesh pocket	Cut 1x mesh fabric, Pattern 5 Cut 1x fold over elastic 5 3/4″ (14.5 cm) long
Adjustable Strap	Cut 1x webbing strap 55" (140 cm) long

Brief Directions

Seam allowances are 1/4" (6mm) unless otherwise stated.

Please watch the Full Video Tutorial along side the below instructions for thorough demonstration, and to avoid any confusion.

Preparation

- 1. Fuse the stabilizer to the wrong side of the back exterior panel according to the manufacturer's instructions (centered).
- 2. Fuse the stabilizer to the wrong side of the lower gusset exterior panel according to the manufacturer's instructions (centered).

Exterior

- 3. Sew the front exterior zipper pocket
- 4. Sew the back exterior pocket then attach it to the right side of the back exterior panel.

Interior

- 5. Bind the top edge of the mesh pocket panel with the foldover elastic.
- 6. Attach the mesh pocket panel on the right side of the front interior panel.
- 7. Sew the back interior zipper pocket.



Zipper Gusset

- 8. Make the zipper gusset.
- 9. Trim off the fabric side so that the zipper gusset will measure 3" (7.5cm) wide.
- 10. Trim off any excess zipper.

D-rings & Adjustable Strap

- 11. Sew the ring tabs, attach the d-rings
- 12. Install the ring tabs on both sides edges of the zipper gusset.
- 13. Make the adjustable strap, set aside.

Lower gusset, assembly, finish

- 14. Join the lower gusset panels to the zipper gusset. Now we're going to call this the gusset panel.
- 15. With the wrong sides facing, sew the front exterior panel and the front interior panel with 1/8" (3mm) seam allowance.
- 16. With the wrong sides facing, sew the back exterior panel and the back interior panel with 1/8" (3mm) seam allowance.
- 17. With the right sides facing, sew the front side of the gusset to the front panel.
- 18. With the right sides facing, sew the back side of the gusset to the back panel.
- 19. Bind the raw edges to finish.

watch the video tutorial https://youtu.be/O1hreXG4dBQ

Terms of use: You may sell the bag that you make with this pattern. Permission to sell is given for small scale home based handmade business.

©Copyright 2024 YoanSewingStudio | All Rights Reserved | Duplication of any kind is prohibited.